


FIG. 1

100






FIG. 2

3/17

121




FIG. 3




FIG. 4

5/17

400




FIG. 5




FIG. 6

7/17




FIG. 7



9/17

500




FIG. 9




FIG. 10




FIG. 11




FIG. 12




FIG. 13




FIG. 14




FIG. 15

SHIFT




1020

MOVE MOUSE OR
PRESS TO SELECT

SEAT CONTROLS
[DRIVER] 1005

PASSENGER [2] [3] [4]

1007



SLIDE OR TOUCH TO ADJUST

ARM REST ADJUSTMENTS
SEAT HEATER ON OFF
SMART SEATS
CUSHION ADJUSTMENT
BACK SUPPORT ADJUSTMENT
AUTO TEMPERATURE CONTROL
MESSAGE ON OFF

FIG. 16

QUICK TIPS

VOICE

VISUAL

DRIVER PASSENGER 1 2 3 4


SMART CLIMATE

AUTO CLIMATE

SET CLIMATE

CLIMATE CONTROL SYSTEM

1021 FRONT VENTS 1023



FAN CONTROLS
VENT CONTROLS
MANUAL AIR VOLUME

WINDSHIELD DEFROST
REAR DEFROST
MIRROR DEFROST

SMART

ALL AUTO DEFROST

TEMPERATURE SET
AIR RECIRCULATION
ACTIVE FILTER SYSTEM
CONTAMINATION ALERT

MORE INFORMATION

SAVE PREFERENCES

WARNING MESSAGES

RESTORE SETTINGS




FIG. 17

FIG. 18

SELECTIONS FROM
MENU OR SCREEN

QUICK TIP: PRESS
ANIMATION TO HEAR AND
SEE DEMO

ANIMATION

VOICE

SEE DEMO

MORE INFORMATION

USER ICON

AUDIO SYSTEM RADIO CASSETTE CD VIDEO TV WEATHER BAND

RADIO STATIONS: XX LOS ANGELES, XX SANTA ANA STATIONS
X IRVINE

SAVE AREA SETTINGS YES NO

SELECTION BEING PLAYED:
XX SONG, XX ALBUM 1245

OTHER

YOU ARE
LISTENING
TO:

1271
FM102.9 AM103.5
AM107.8

1273
FM100.7

1275
★
AM79.00

10 COUNTRY: FM102.9 AM103.5
8 TALK/NEWS: FM89.9 FM91.2 AM98.6 AM107.0

5 ROCK: FM89.3 FM98.1

AM990 FM102.7 FM107.90

2 CLASSIC: FM91.4 FM96.4

1277

SET FOR: DRIVER PASSENGER 1 2 3 4 5

ON OFF VOLUME CONTROL BASS TREBLE

FADER CONTROLS FRONT LEFT RIGHT
BACK LEFT RIGHT

MOVE SPEAKERS FOR
DESIRED SOUND
EFFECTS

PRESS EFFECT THEN
SPEAKER
ROCK
SURROUND
MOVIE
ETC.

1251 1255 1257

1253

QUICK TIP: SCROLL FOR
XX MORE STATIONS
USE MOUSE CONTROLS
OR PRESS TO SELECT

QUICK TIP: ANTENNA
IS ACTIVATED BY
RADIO AND TELEPHONE,
BOTH MUST BE
SWITCHED OFF TO
LOWER ANTENNA

STEREO

SMART AUDIO

RESTORE SETTINGS

DOLBY

AUTO RADIO

MORE INFORMATION

DIGITAL
ENCODED

SAVE PREFERENCES